



Rebuild instructions:

1. Do not proceed if you are not qualified for this work
2. Make breaker & mechanism safe for work
3. Disassemble and gently clean valve
4. Reassemble using new seals per drawing
5. Items 12 & 13 are used with older main valves
6. Item 3 is used with newer main valves
7. Take special note of the location of item 19
8. Sparngly lubricate orings with Parker Superlube

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF BREAKER SERVICE INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF BREAKER SERVICE INC. IS PROHIBITED.
 COPYRIGHT 2005

BREAKER SERVICE INC		
800-828-5250 office 888-267-7690 fax		
Rebuild kit for Norgren pilot valve model D0035C or D00105.		
Items shown with asterisk * are included in this repair kit		
REV	DWG. NO.	REV.
A	15028	0
SCALE: N/A	Date: 04-10-2005	SHEET 1 OF 1